





# SPARE PARTS LIST

LAWN MOWERS

ELECTRIC LAWNMOWER POWER MAX  
32 E, Art. 4033-20, 2011-09

**GARDENA** Elektro-Rasenmäher PowerMax 32 E Art.-Nr. 4033



Ref	Part no.	Description	Remark	Qty	Kit
2	513 85 74-00	CLAMP	62551-38.574.00	1	
3, 43-52	525 61 10-01	ASSEMBLY	62552-56.110.01	1	
1, 3, 43-52	525 61 09-01	ASSEMBLY	62552-56.109.01	1	
3, 43-52	525 61 11-01	ASSEMBLY	62552-56.111.01	1	
4	514 02 66-00	WASHER	62551-40.266.00	1	
5	522 90 06-01	KNOB	62552-29.006.01	1	
6	514 91 98-01	BOLT	62551-49.198.01	1	
7	510 76 26-00	SPARE PARTS	62551-07.626.00	1	
10	522 90 09-01	KIT	62552-29.009.01	1	
10-12	522 90 12-01	HANDLE	62552-29.012.01	1	
14	522 90 13-01	LID	62552-29.013.01	1	
15	522 90 17-01	GRASSBAG	62552-29.017.01	1	
16	522 91 35-01	TONGUE	62552-29.135.01	1	
17	522 90 18-01	FLAP	62552-29.018.01	1	
18	510 76 19-00	SPARE PARTS	62551-07.619.00	1	
19	514 88 59-04	BOLT	62551-48.859.04	1	
21	510 76 21-00	SPARE PARTS	62551-07.621.00	1	
22	522 90 34-01	MOTOR ASSY	62552-29.034.01	1	
	510 77 02-00	SPARE PARTS	62551-07.702.00, not shown in image	1	
23	510 76 03-00	SPARE PARTS	62551-07.603.00	1	
24	510 76 05-00	SPARE PARTS	62551-07.605.00	1	
25	522 90 19-01	SCREW	62552-29.019.01	1	
26	510 76 17-00	SPARE PARTS	62551-07.617.00	1	
27	522 90 20-01	DECK	62552-29.020.01	1	
28, 29	510 76 09-00	SPARE PARTS	62551-07.609.00	1	
30	525 63 26-01	SPARE BLADE	4080-00.701.00	1	
31	522 90 22-01	WASHER	62552-29.022.01	1	
34	522 90 31-01	SPACER	62552-29.031.01	1	
35	522 90 24-01	WHEEL	62552-29.024.01	1	
36	522 90 33-01	WASHER	62552-29.033.01	1	
37	522 90 25-01	HUB CAP	62552-29.025.01	1	
40	522 90 28-01	DECK	62552-29.028.01	1	
42	522 90 23-01	LEVER	62552-29.023.01	1	
43-52	525 61 06-01	SWITCHBOX	62552-56.106.01	1	
43-52	525 61 05-01	SWITCHBOX	62552-56.105.01	1	
43-52	525 61 07-01	SWITCHBOX	62552-56.107.01	1	
49	513 12 16-00	CAPACITOR	62551-31.216.00	1	
52	522 72 08-01	SWITCHBOX	62552-27.208.01	1	
53	513 11 17-00	PIN RETAINER	62551-31.117.00	1	
54	510 76 18-00	SPARE PARTS	51-07.618.00	1	