




SPARE PARTS LIST

LAWN MOWERS: ELECTRIC

SPEEDI-MO 360VC/360C, 967663401,
967663462, 967663301, 967663362,
2017-05



ASSEMBLY SPEEDI-MO 360VC/360C, 967663401, 967663462, 967663301, 967663362, 2017-05

Ref	Part No	Description	Remark	QTY	KIT
590584201	590 58 42-01	COLLECTOR	Grassbox Assy w/Tongue	1	53-56, 58
590584401	590 58 44-01	DUCT	Tongue	1	58
590581701	590 58 17-01	FLAP	Safety Flap w/Spring	1	26, 31
590584501	590 58 45-01	FLAP	Safety Flap Fixings	1	29, 30
590577301	590 57 73-01	HANDLE	Lower	1	57
590584601	590 58 46-01	BLADE	Blade Bolt and Washer	1	71, 72
590577401	590 57 74-01	MOTOR	Motor	1	9-11, 39
590581901	590 58 19-01	BELT	Belt	1	32
590582001	590 58 20-01	BASEPLATE	Baseplate	1	21-25, 33-37
590582101	590 58 21-01	CABLE	Internal Cable	1	49
510762701	510 76 27-01	HANDLE	Upper Handle	1	48
590584701	590 58 47-01	BASEPLATE	Motor & Baseplate Screws (qty. 10)	1	38
590582301	590 58 23-01	BOTTLE	Bottle	1	74
590582401	590 58 24-01	WHEEL ASSY	Rear Wheel Assy	1	14, 18-20
590582501	590 58 25-01	WHEEL ASSY	Front Wheel Assy	1	12-15
590581801	590 58 18-01	COVER	Height Adjust Cover	1	16, 64, 65
590582601	590 58 26-01	HEIGHT ADJUSTER	Height Adjust w/Springs	1	16, 60-63, 66
590582701	590 58 27-01	LEVER	Height Adjust Lever	1	59
590582801	590 58 28-01	DECK	Deck	1	27
590582901	590 58 29-01	PLATE	Sole Plate	1	16, 73
590583101	590 58 31-01	FRONT AXLE	Front Wheel Axle	1	16, 67-69
590583201	590 58 32-01	REAR AXLE	Rear Wheel Axle	1	16, 28, 68
590605190	590 60 51-90	MOWER BLADE	Blade	1	70
590583601	590 58 36-01	INLET	Right Air Intake	1	16, 17
590583401	590 58 34-01	FILTER	Air Filter Kit	1	5, 8
590583501	590 58 35-01	COVER	Motor Cover	1	1-4, 16
511956390	511 95 63-90	KIT	Wing Knob Assy	1	50, 51, 52
7	510 76 06-00	SCREW KIT	Pack of 10	1	
14	577 17 81-01	LOCKWASHER	Pack of 4	1	
75	513 85 74-00	CLAMP	Cable Clip	1	
77	513 08 73-00	SCREW	Pack of 6	4	
78	510 73 09-68	SWITCHBOX	Lower - Euro Inlet	1	
78	510 77 05-00	SWITCHBOX	Lower - Hardwired	1	
79	510 76 28-00	LEVER	Switchbox	1	
80	574 64 57-01	PEN	Retainer - Euro	1	
81	522 72 09-02	SWITCH	Switchbox	1	
82	513 12 16-00	CAPACITOR	Capacitor	1	
83	510 79 03-00	POWER CORD	Power Cord	1	
84	511 94 56-68	SWITCHBOX	Upper	1	
85	513 10 30-64	BUTTON	Lock Off	1	
86	577 29 84-01	CLIP	Cable Clip	1	