




SPARE PARTS LIST

LAWN MOWER; ELECTRIC
EASIGLIDE PLUS 330V,
970483701, 970483762

2020-11

PRODUCT COMPLETE

EASIGLIDE PLUS 330V 970483701, 970483762, 2020-11



PRODUCT COMPLETE

EASIGLIDE PLUS 330V 970483701, 970483762, 2020-11

Ref	Part No	Description	Remark	QTY KIT
1, 2	529 62 70-01	Switchbox (UK)		1
1, 2	529 82 77-01	Switchbox (EU)		1
3	577 29 83-01	Screws		6
4	513 12 16-00	Switch		1
5	522 72 09-02	Capacitor		1
6	599 83 65-01	Start Button		1
7	599 84 99-01	Levers		2
8	512 80 31-05	Mains Cable (UK)		1
8	529 82 83-01	Switchbox Connector (EU)		1
9	529 62 96-01	Grass Box Handle		1
10	529 62 97-01	Grass Box Cover		1
11 – 13	529 62 91-01	Grass Box		1
15	577 29 84-01	Cable Clips		2
16 – 18	599 83 63-01	Cable Hook Kit		1
19	529 63 01-01	Handle Bolt Kit		2
20	529 62 99-01	Lower Handle		1
21, 22	529 63 00-01	Rear Bumper		1
25	529 62 98-01	Grass Box Lid		1
26, 27, 29	529 62 89-01	Motor Cowl Kit		1
28	529 62 78-01	Air Filter Kit		2
30 – 32	529 62 83-01	Roller Kit		1
33	529 62 84-01	Belt		1
34	529 62 86-01	Impeller		1
35	529 36 32-90	Washers		3
36	529 37 07-90	Blade (FLY095)		1
37, 38	529 62 87-01	Blade Bolt Kit		1
39	529 62 88-01	Spanner		1
40	529 63 24-01	Power Cable		1