




SPARE PARTS LIST

LAWN MOWERS; BATTERY
EASISTORE 340R Li, 967987801,
2020-06

PRODUCT COMPLETE

EasiStore 340R Li 967987801 2020-06



PRODUCT COMPLETE

EASISTORE 340R Li 967987801 2020-06

Ref	Part No	Description	Remark	QTY KIT
1, 2	599 83 59-01	Blade Bolt		1
3	599 13 46-90	Blade (FLY087)		1
4	599 84 74-01	Blade Spacer		1
5, 6	599 84 81-01	Axle Bracket		1
7	577 17 79-01	140 mm Wheel Kit	Incl 9	1
8	577 17 80-01	140 mm Hub Cap		1
9, 12	599 89 20-01	Starlock Washer Domed Grey		4
10	599 84 72-01	160 mm Hub Cap		1
11	599 84 63-01	160 mm Wheel Kit	Incl 12	1
13	599 85 01-01	Spring & Screw		1
14 – 18	599 83 87-01	Fixing Kit Quick Release Assy		1
19	599 84 71-01	Bolt		1
21	599 84 61-01	Roller		1
22, 23	599 84 69-01	Washer & Screw		1
25	599 80 22-01	Grass Box Tongue		1
26, 27	599 83 96-01	Grass Flap Assy		1
28, 29	599 80 47-01	Grass Box Upper & Lower		1
30	599 80 24-01	Full Bag Indicator		1
31	599 83 52-01	Air Filter		1
32, 33	599 84 75-01	Isolator Switch		1
35	589 62 99-01	Isolator Key		1
36 – 38	599 84 73-01	Battery Cover Assy		1
39	599 85 24-01	Power Cable		1
40 – 42	599 83 54-01	Fixing Kit Wingknob Grey		1
46 – 48	599 80 10-01	Grass Box Handle + Hook		1
49	599 83 64-01	Switchbox Triggers Grey		2
50, 52	599 83 68-01	Switch Box Case		1
51	599 83 92-01	Switch		1
53	599 83 65-01	Switchbox Start Button Grey		1
-	577 29 83-01	Screws Switchbox		6
-	599 83 60-01	Screws Housing		20
-	967 91 32-01	Battery		1
-	967 91 33-01	Charger UK		1
-	967 91 33-62	Charger EU		1