




SPARE PARTS LIST

LAWN MOWERS; BATTERY
36 V EASISTORE 340R Li,
970538201, 970538301, 2021-11



Ref	Part No	Description	Remark	QTY KIT
1, 2	599 83 59-01	Blade Bolt		1
3	599 13 46-90	Blade (FLY087)		1
4	599 84 74-01	Blade Spacer		1
5, 6	599 84 81-01	Axel Bracket		1
7	577 17 79-01	140 mm Wheel Kit	Incl. 9	1
9	599 89 19-01	Starlock Washer Domed Black		4
11	599 84 63-01	160 mm Wheel Kit	Incl. 9	1
13	599 85 01-01	Spring & Screw		1
14 – 18	599 83 87-01	Fixing Kit Quick Release Assy		1
19	599 84 71-01	Bolt		1
21	599 84 61-01	Roller		1
24	531 38 22-01	Charger		1
25	599 80 22-01	Grass box Tongue		1
26, 27	536 47 70-01	Grass Flap Assy		1
28, 29	599 80 47-01	Grass box upper & lower		1
30	599 80 24-01	Full Bag Indicator		1
31	536 47 69-01	Air Filter		1
32, 33	599 84 75-01	Isolator Switch		1
35 - 38	536 47 68-01	Battery Cover Assy		1
39	589 62 99-01	Isolator Key		1
40 – 42	599 83 54-01	Fixing Kit Wingknob Grey		1
46 – 48	599 80 10-01	Grass Box Handle + Hook		1
49 - 56	536 47 64-01	Switch Box Assy		1
57	599 99 76-01	2 Ah Battery		1
57	531 38 26-01	2.5 Ah Battery		1
57	531 38 27-01	4 Ah Battery		1