




SPARE PARTS LIST

LAWN MOWERS; BATTERY
SIMPLISTORE 300 Li, 970539501,
2021-11



Ref	Part No	Description	Remark	QTY KIT
1, 2	599 83 59-01	Blade Bolt		1
3	589 81 83-90	Blade (FLY069)		1
4	599 83 52-01	Air Filter		1
5, 8	599 89 19-01	Starlock Washer Domed Black		4
6, 9	577 17 80-01	Hub Cap		1
7, 10	577 17 79-01	140mm Wheel Kit	Incl. 5	1
11 - 13	599 83 61-01	Roller Assy		1
14	599 79 58-01	Grass Box Tongue		1
15, 16	599 79 67-02	Grass Box Assy		1
17	599 83 66-01	Belt		1
21	589 62 99-01	Isolator Key		1
22	599 83 90-01	Isolator Switch		1
18, 19, 23	599 83 67-02	Battery Cover Assy		1
24	599 85 21-01	Power Cable		1
25 – 29	599 83 87-01	Fixing Kit Quick Release Assy		1
32, 33	599 83 55-01	Grass Flap Assy		1
34 – 36	599 83 54-01	Fixing Kit Wingknob Grey		1
40 – 42	599 80 10-01	Grass Box Handle + Hook		1
43	599 83 64-01	Switchbox triggers Grey		2
44, 46	599 83 68-01	Switch Box Case		1
45	599 83 92-01	Switch		1
47	599 83 65-01	Switchbox Start button Grey		1
-	577 29 83-01	Screws Switchbox		6
-	599 83 60-01	Screws Housing		20
-	967 91 32-01	Battery		1
-	967 91 33-01	Charger UK		1
-	967 91 33-62	Charger EU		1