

Art. 1739

D Gebrauchsanweisung
Elektronischer Druckschalter

GB Operating Instructions
Electronic Pressure Switch

F Mode d'emploi
Interrupteur manométrique électronique

NL Gebruiksaanwijzing
Elektronische drukschakelaar

S Bruksanvisning
Elektronisk tryckströmkontroll

I Istruzioni per l'uso
Pressostato elettronico

E Manual de instrucciones
Interruptor electrónico de presión

P Instruções de utilização
Interruptor electrónico de pressão

DK Brugsanvisning
Elektronisk manometer

GARDENA Electronic Pressure Switch

Welcome to the Garden of GARDENA ...

GB



Please read the Instructions for Use carefully and follow the instructions contained in them. Get to know the Electronic Pressure Switch, its correct use and the safety instructions with the assistance of these Instructions for Use.



For safety reasons, children and young persons under the age of 16 and people who have not read these Instructions for Use should not use this Electronic Pressure Switch.

Contents

► Please keep these instructions in a safe place.	
1. Area of Application of Your GARDENA Electronic Pressure Switch	10
2. For Your Safety	10
3. Function and Display	11
4. Assembly	12
5. Putting into operation	13
6. Operating	13
7. Maintenance	14
8. Trouble-Shooting	14
9. After Operation	15
10. Accessories	15
11. Technical Data	16
12. Service	16

1. Area of Application of Your GARDENA Electronic Pressure Switch

Intended use

The GARDENA Electronic Pressure Switch is used for converting garden pumps into automatic domestic water system for private use in domestic gardens and allotments.

Please note



The pump used must reach a pressure of at least 2.5 bar at the intake for the Electronic Pressure Switch.

2. For Your Safety



Warning! Electric shock!

Risk of injury due to electric shock.

- Always unplug your Garden Pump before filling, after operation, when trouble-shooting and before carrying out any maintenance work.

Location

Warning: Using a pump converted with the electronic pressure switch on swimming pools, garden ponds and similar locations is only permis-

sible if the pump is operated via a fault current circuit-breaker (FI-switch) (DIN VDE 0100-702 and 0100-738). In addition, the pump must be set up so that it is stable and cannot be flooded and must be protected to prevent it falling. An approved RCD powerbreaker can be used as an additional safety device.

- Please ask your electrician for his advice.

Take care that the site is firm and solid, in order to ensure safe location of the pump.

- Locate the pump at safe distance of the liquid.

Extension cables

The Electronic Pressure Switch may only be operated with 230 V / 50 Hz.

→ Note mains voltage.

Pursuant to DIN VDE 0620, power cable as well as extension cables must not have a smaller diameter than rubber sheathed cables described with letter symbols H07 RNF.

→ Ensure that the plug and socket connections are arranged in an area which cannot flood.

In Austria

In Austria, the electrical connections must be made according to ÖVE-EM 42, T2 (2000)/1979 § 22 based on § 2022. Pursuant to this regulation it's imperative to operate pumps for swim-

ming pools and garden ponds exclusively via an isolating transformer.

→ Please ask your electrician.

In Switzerland

In Switzerland mobile appliances which are used outdoors, must be connected via a residual-current device.

Visual check

→ Always inspect before use to ensure that the equipment, especially the plug and the cable, are not damaged.

A damaged unit must not be used.

→ If damaged, have the Electronic Pressure Switch checked by GARDENA Service or an authorised electrician.

3. Function and Display

The Electronic Manometric Switch is equipped with an electronic control unit with fixed programs. The electronic control unit is activated by pulses from the manometric switch and the flow recognition of the dry-running safety feature.

The manometric switch is set at the factory to a switching pressure of approx. 2.2 bar. This setting cannot be changed. The dry-running safety mechanism protects the pump against damage and controls the time the pump continues to run against the closed delivery side.

Explanation of terms

Normal operation

The pump has reached the maximum pump pressure and switches off automatically.

Suction cycle

The pump attempts to resume **normal operation** after 4 minutes.


Automatic self-priming mode

(yellow **ALARM LED** flashes)

After a fault, the pump's electronic control unit makes three automatic self-priming attempts at different time intervals (after 1 hour, after 5 hours and after 20 hours) to restore **normal operation**. The **priming cycle** (see above) is used for each of these attempts.

RESET key:

You can switch the pump on again prematurely at any time by pressing the **RESET** key. If the warning LED is flashing, however, the pump can only be turned on again by unplugging the mains plug and then plugging the plug back in again.



Electronic control display

① RESET key:

Resets the pump after a fault occurs.

② Red POWER LED:

Indicates that the pump is connected to the mains power supply.

③ Green Pump ON LED:

Indicates that the pump is pumping.

④ Yellow ALARM (No Water) LED:

Indicates a fault.

Red POWER LED ② is on

Green Pump ON LED ③ is on

Green Pump ON LED ③ flashes slowly (1 x per second.)

Green Pump ON LED ③ flashes quickly (4 x per second.)

Yellow ALARM LED ④ flashes slowly (1 x per second.)

Yellow ALARM LED ④ flashes quickly (4 x per second.)

Yellow ALARM LED ④ is on

Green Pump ON LED ③ and yellow ALARM LED ④ flash alternately

Operating states

The pump is operating in the **normal operating mode**.

The pump is pumping. Once the pump has reached the max pump pressure, the pump switches off (the green **Pump ON LED** extinguishes) and the pump functions in the **normal operating mode**.

The delivery rate is too low at the **delivery side** (less than 90 l / h). The pump continues to pump for a moment then switches off. The pump switches on again as soon as the pressure reaches the switching pressure of approx. 2.2 bar (e.g. if there is a leak) - or the pump is about to switch off after you have finished drawing off water.

The flow rate on the **inlet side** is too low (below 300 l / h).

The pump continues to run for approx. 40 seconds. If normal operation is not achieved during this time, the pump switches off and the control unit changes to the "**automatic selfpriming mode**".

The amount of water is too low when restarting the pump.

The pump runs through the first "**priming cycle**". If the normal operating mode is not achieved, the pump switches off and the control unit changes to the "**automatic self-priming mode**".


Alarm which indicates if the amount of water is too low when the pump is operating in the normal mode. The control unit changes to the "**automatic self-priming mode**".

The "**automatic self-priming mode**" is no longer active and the unit is no longer supplying water (e.g. no water in the container or bore or the filter is dirty).

Warning: There is a leak in the pipe system. The pump switches on and off because of a leak. If the pump switches on and off more than 7 times within 2 minutes, the control unit issues a warning via flashing LEDs and the motor switches itself off.


4. Assembly

Fit pressure switch on the pump:




The Electronic Pressure Switch provided with a 33.3 mm (G 1) external thread on the input side ①.

1. For GARDENA pumps: art.1422/1429/1432/1434/1438/1442 screw adapter ② on to the pump and screw sealing cap ③ on the side pressure connection.
2. Place pressure switch ④ on the pump.
3. Hold the pressure switch ④ with one hand and screw the lower rotating part ⑤ into the pump as far as the stop.
4. When you reach the stop, turn the non-return valve ⑥ anti-clockwise (max. 1 turn) to the position required.
5. Plug mains plug ⑦ of the pump into the socket ⑧ of the pressure switch ④ (behind the display).



5. Putting into operation

Connect the hose to the suction side:



Don't use any hose connection system fittings on the suction side! A vacuum-resistant suction hose must be used

- e.g. GARDENA Suction Unit, **Art. no. 1411**.

To shorten the time required for suction to start again, we recommend the use e.g. of the GARDENA suction filter with backflow preventer, **Art. 1728**, combined with the GARDENA suction hose, **Art. 1412**, which prevents the suction hose emptying automatically when the automatic domestic water systems are shut down.

- Remove the flat gasket of the suction hose and replace it with the dirt filter ⑨ provided.

Alternatively, you can also use the GARDENA Pump Preliminary Filter, **Art. no. 1730/1731**.

It is important to filter the water to prevent contaminating the manometric switch.

Connect the hose to the delivery side:

The 33.3 mm (G1) inner thread at the outlet of the Electronic Manometric Switch can be modified if necessary to an outer thread by using the GARDENA Pump Fitting, **Art. No. 1745**, which can be fitted to the GARDENA Water Hose Connection System.

For pumps fitted with an horizontal 33.3 mm (G 1) outer thread we recommend the use of the GARDENA Brass Angle with inner thread, **Art. No. 7281**. The connections have to be sealed with commercial agents.


6. Operation

Switch on Electronic Pressure Switch:



Warning! Electric shock!
Risk of injury due to electric shock.

- Disconnect the Electronic Pressure Switch from the mains before filling it.



1. Turn rotary switch ⑩ of the non-return valve to **position 2**. (valve opened).
2. Open filler pipe of pump (to vent it).
3. Fill with liquid to be pumped via the outlet pipe ⑪ until it reaches the overflow.
4. Open any shut-off devices in the delivery line (watering accessories, water stop, etc.) so that air can escape before the priming procedure begins.
5. Drain remaining water in pressure hose so that air can escape during the suction process.


The mains plug of the pump must be plugged into the manometric switch!

6. Switch ON/OFF switch of pump (if present) to "ON".
7. Plug the pump into a 230 V/50 Hz alternating current socket ⑫.

Warning: The pump will start immediately!

8. When the pump has begun pumping, turn the rotary switch ⑩ of the return valve to **position 1** (normal operating mode).


- If the pump does not deliver liquid after 7 minutes, unplug the manometric switch ⑫ (see "8. Trouble Shooting").



It is advantageous to fill the suction hose as well if the pump has to overcome a large self-priming suction height, or if the suction hose has a diameter $\geq 1"$ (25.4 mm).

7. Maintenance

Decalcifying the electronic manometric switch:



Warning ! Electric shock!

Risk of injury due to electric shock.

► Disconnect the Electronic Pressure Switch from the mains before undertaking any maintenance.

1. Reduce the pressure (e. g. by opening a valve).
2. Loosen the pressure hose and fill the manometric switch ④ with water containing vinegar or a household decalcifying product.
3. Rinse the manometric switch ④ thoroughly after decalcifying.

8. Trouble Shooting



Warning ! Electric shock!

Risk of injury due to electric shock.

► Disconnect the Electronic Pressure Switch from the mains before undertaking any work to rectify faults.

Problem	Probable cause	Remedy
Warning flashing (green Pump ON LED and yellow ALARM LED flash alternately)	Faulty or leaking back-flow preventer at the end of the suction hose Pump and suction hose are not filled up with the liquid to be pumped Backflow valve switch set to position 2 and was not set to position 1 once the pump began pumping Suction hose end is not submerged into the liquid Outlet too low Suction hose or connections are not water-tight Suction filter clogged Air cannot escape on delivery side since release points are closed etc. Delivery pipe or consumer are not water-tight	1. Unplug the manometric switch. 2. Rectify the fault. 3. Plug the manometric switch back in again. Shouldn't the pump start priming, although you have repeatedly pressed the RESET button, please contact one of our GARDENA Service Centres (addresses you will find on the rear side).
Pump switches on and off continuously if liquid is drawn at a rate greater than 400 l / h.	Dirt has collected on the manometric switch.	1. Remove manometric switch from pump. 2. Return valve set to position 2 . 3. Rinse manometric switch.

Pump doesn't start or suddenly stops during operation.	No power. Electronic Manometric Switch calcified.	→ Check fuses and electric connections. → Decalcify the Electronic Manometric Switch.
Pump constantly cuts in and out without drawing water.	Leak on the pressure side. Note: Even the smallest leak (loss of a few mls) can cause the pressure in the pump to drop. The cause of this is often small leaks at taps and toilet flushing cisterns.	1. Check the pressure line and connected consumers for leaks. 2. The non-return valve shall be at position 1 when localising faults.
	There being deposits of dirt in the Electronic Manometric Switch.	1. Loosen the Electronic Manometric Switch from the pump. 2. Turn the non-return valve to position 2 . 3. Clean the non-return valve, e.g. by flushing in the direction of flow.
Pump does cut out.	Rotary switch / non-return valve is set to position 2 . Non-return valve of the Electronic Manometric Switch is blocked. Larger leaks on the pressure side.	→ Set the rotary switch to position 1 . → Clean the non-return valve, e.g. by flushing in the direction of flow. → Rectify leaks.
Pump doesn't start working.	Outlet end (e.g. water accessory) is closed. There is sufficient water pressure in the pressure line.	→ Open the outlet end.

In addition to this, please observe the notes on use given in the operating instructions for the applicable garden pump.

If you have any other problem with your Garden Pump, please contact our Customer Service.

9. After Operation

Wintering / Storage → Drain the pump and the Electronic Manometric Switch before the frost period sets in. Store them protected from frost.

10. Accessories

GARDENA Suction Filter	To equip suction hoses with Backflow Preventer sold by the metre.	• Art. no. 1726/1727/1728
GARDENA Pump Preliminary Filter	Recommended for pumping sandy liquids.	• Art. no. 1730 / 1731
GARDENA Bore Hole Suction Hose	For vacuum-resistant connection of the pump to boreholes or pipe networks. Length 0.5 m. With 33.3 mm (G1) female thread at both ends.	• Art. no. 1729

11. Technical Data

Typ	Art. 1739
Cut-in pressure after pressure drop	2,2 ± 0,2 bar
Max. pressure	6 bar
Max. rate of flow	8400 l/h
Min. flow regulated at pressure side	90 l/h
Min. flow regulated at suction side	300 l/h
Max. ambient temperature	35 °C
Voltage/Frequency	230 V AC / 50 Hz
Max. current	8 A
Degree of protection/Protection class	IP 44 / I

12. Service

Warranty

GARDENA guarantees this product for 2 years (from date of purchase).

This guarantee covers all serious defects of the unit that can be proved to be material or manufacturing faults. Under warranty we will either replace the unit or repair it free of charge if the following conditions apply:

- The unit must have been handled properly and in keeping with the requirements of the operating instructions.
- Neither the purchaser or a non-authorised third party have attempted to repair the unit.

This manufacturer's guarantee does not affect the user's existing warranty claims against the dealer/seller.

If a fault occurs with your Garden Pump, please return the faulty unit together with a copy of the receipt and a description of the fault, with postage paid to one of the GARDENA Service Centres listed on the back of these operating instructions.

D Produkthaftung	Wir weisen ausdrücklich darauf hin, dass wir nach dem Produkthaftungsgesetz nicht für durch unsere Geräte hervorgerufene Schäden einzustehen haben, sofern diese durch unsachgemäße Reparatur verursacht oder bei einem Teileaustausch nicht unsere originale GARDENA Teile oder von uns freigegebene Teile verwendet wurden und die Reparatur nicht vom GARDENA Service oder dem autorisierten Fachmann durchgeführt wird. Entsprechendes gilt für Ergänzungsteile und Zubehör.
GB Product Liability	We expressly point out that, in accordance with the product liability law, we are not liable for any damage caused by our units if it is due to improper repair or if parts exchanged are not original GARDENA parts or parts approved by us, and, if the repairs were not carried out by a GARDENA Service Centre or an authorised specialist. The same applies to spare parts and accessories.
F Responsabilité	Nous vous signalons expressément que GARDENA n'est pas responsable des dommages causés par ses appareils, dans la mesure où ces dommages seraient causés suite à une réparation non conforme, dans la mesure où, lors d'un échange de pièces, les pièces d'origine GARDENA n'auraient pas été utilisées, ou si la réparation n'a pas été effectuée par le Service Après-Vente GARDENA ou l'un des Centres SAV agréés GARDENA. Ceci est également valable pour tout ajout de pièces et d'accessoires autres que ceux préconisés par GARDENA.
NL Productaansprakelijkheid	Wij wijzen er nadrukkelijk op, dat wij op grond van de wet aansprakelijkheid voor producten niet aansprakelijk zijn voor schade ontstaan door onze apparaten, indien deze door onvakkundige reparatie veroorzaakt zijn, of er bij het uitwisselen van onderdelen geen gebruik gemaakt werd van onze originele GARDENA onderdelen of door ons vrijegeven onderdelen en de reparatie niet door de GARDENA technische dienst of de bevoegde vakman uitgevoerd werd. Ditzelfde geldt voor extra-onderdelen en accessoires.
S Produktansvar	Tillverkaren är inte ansvarig för skada som orsakats av produkten om skadan beror på att produkten har reparerats felaktigt eller om, vid reparation eller utbytte, andra än Original GARDENA reservdelar har använts. Samma sak gäller för kompletteringsdelar och tillbehör.
I Responsabilità del prodotto	Si rende espressamente noto che, conformemente alla legislazione sulla responsabilità del prodotto, non si risponde di danni causati da nostri articoli se originati da riparazioni eseguite non correttamente o da sostituzioni di parti effettuate con materiale non originale GARDENA o comunque da noi non approvato e, in ogni caso, qualora l'intervento non venga eseguito da un centro assistenza GARDENA o da personale specializzato autorizzato. Lo stesso vale per le parti complementari e gli accessori.
E Responsabilidad de productos	Advertimos que conforme a la ley de responsabilidad de productos no nos responsabilizamos de daños causados por nuestros aparatos, siempre y cuando dichos daños hayan sido originados por arreglos o reparaciones indebidas, por recambios con piezas que no sean piezas originales GARDENA o bien piezas no autorizadas por nosotros, así como en aquellos casos en que la reparación no haya sido efectuada por un Servicio Técnico GARDENA o por un técnico autorizado. Lo mismo es aplicable para las piezas complementarias y accesorios.
P Responsabilidade sobre o produto	Queremos salientar que segundo a lei da responsabilidade do fabricante, nós não nos responsabilizaremos por danos causados pelo nosso equipamento, quando estes ocorram em decorrência de reparações inadequadas ou da substituição de peças por peças não originais da GARDENA, ou peças não autorizadas. A responsabilidade tornar-se-á nula também depois de reparações realizadas por oficinas não autorizadas pela GARDENA. Esta restrição valerá também para peças adicionais e acessórios.
DK Produktansvar	Vi gor udtrykkeligt opmærksom på at i henhold til produktansvarsloven er vi ikke ansvarlige for skader forårsaget af vores udstyr, hvis det er på grund af uautoriserede reparationer eller hvis dele er skiftet ud og der ikke er anvendt originale GARDENA dele eller dele godkendt af os, eller hvis reparationerne ikke er udført af GARDENA-service eller en autoriseret fagmand. Det samme gælder for ekstra udstyr og tilbehør.

<p>D EU-Konformitätserklärung</p> <p>MaschinenVerordnung (9. GSGVO) / EMVG / Niedersp. RL</p> <p>Der Unterzeichnete GARDENA Kress + Kastner GmbH · Hans-Lorenser-Straße 40 · D-89079 Ulm bestätigt, dass die nachfolgend bezeichneten Geräte in der von uns in Verkehr gebrachten Ausführung die Anforderungen der harmonisierten EU-Richtlinien, EU-Sicherheitsstandards und produktspezifischen Standards erfüllen. Bei einer nicht mit uns abgestimmten Änderung der Geräte verliert diese Erklärung ihre Gültigkeit.</p>	<p>Bezeichnung des Gerätes: Description of the unit: Désignation du matériel :</p> <p>Omschrijving van het apparaat: Produktbeskrivning: Descrizione del prodotto: Descripción de la mercancía: Descrição do aparelho: Beskrivelse af enhederne:</p> <p>Elektronischer Druckschalter Electronic Pressure Switch Interrupteur manométrique électronique Elektronische druckschakelaar Elektronisk tryckströmsättare Pressostato elettronico Interruptor electrónico de presión Interruptor electrónico de pressão Elektronisk manometer</p>
<p>GB EU Certificate of Conformity</p> <p>The undersigned GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm hereby certifies that, when leaving our factory, the units indicated below are in accordance with the harmonised EU guidelines, EU standards of safety and product specific standards. This certificate becomes void if the units are modified without our approval.</p>	<p>EU-Richtlinien: EU directives: Directives européennes : 89/336/EG</p> <p>EU-richtlijnen: EU direktiv: Directive UE: Normativa UE: 93/68/EG</p> <p>EU-Retningslinier:</p>
<p>F Certificat de conformité aux directives européennes</p> <p>Le constructeur, soussigné : GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm déclare qu'à la sortie de ses usines le matériel ci-dessous était conforme aux prescriptions des directives européennes énoncées ci-après et conforme aux règles de sécurité et autres règles qui lui sont applicables dans le cadre de l'Union européenne. Toute modification portée sur ce produit sans l'accord express de GARDENA supprime la validité de ce certificat.</p>	<p>EU-Richtlinien: EU directives: Directives européennes : 89/336/EG</p> <p>EU-richtlijnen: EU direktiv: Directive UE: Normativa UE: 93/68/EG</p> <p>EU Retningslinier:</p>
<p>NL EU-overeenstemmingsverklaring</p> <p>Ondergetekende GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm bevestigt, dat de volgende genoemde apparaten in de door ons in de handel gebrachte uitvoering voldoen aan de eis van, en in overeenstemming zijn met de EU-richtlijnen, de EU-veiligheidsstandaard en de voor het product specifieke standaard. Bij een niet met ons afgestemde verandering aan de apparaten verliest deze verklaring haar geldigheid.</p>	
<p>S EU Tillverkarintyg</p> <p>Undertecknad firma GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm intygar härmed att nedan nämnda produkter överensstämmer med EU:s direktiv, EU:s säkerhetsstandard och produktspecifikation. Detta intyg upphör att gälla om produkten ändras utan vårt tillstånd.</p>	
<p>I Dichiarazione di conformità alle norme UE</p> <p>La sottoscritta GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm certifica che il prodotto qui di seguito indicato, nei modelli da noi commercializzati, è conforme alla direttive armonizzate UE nonché agli standard di sicurezza e agli standard specifici del prodotto. Qualunque modifica apportata al prodotto senza nostra specifica autorizzazione invalida la presente dichiarazione.</p>	<p>Anbringungsjahr der CE-Kennzeichnung: Year of CE marking: Date d'apposition du marquage CE : Installatiejaar van de CE-aanduiding: CE-Märkningsår: 1997</p>
<p>E Declaración de conformidad de la UE</p> <p>El que subscribe GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm declara que la presente mercancía, objeto de la presente declaración, cumple con todas las normas de la UE, en lo que a normas técnicas, de homologación y de seguridad se refiere. En caso de realizar cualquier modificación en la presente mercancía sin nuestra previa autorización, esta declaración pierde su validez.</p>	<p>Anno di rilascio della certificazione CE: Colocación del distintivo CE: Ano de marcação pela CE: CE-Mærkningsår:</p>
<p>P Certificado de conformidade da UE</p> <p>Os abaixo mencionados GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm Por este meio certificam que ao sair da fábrica os aparelhos abaixo mencionados estão de acordo com as directrires harmonizadas da UE, padrões de segurança e de produtos específicos. Este certificado ficará nulo se as unidades forem modificadas sem a nossa aprovação.</p>	<p>Ulm, den 1.12.1999 Ulm, 1.12.1999 Fait à Ulm, le 1.12.1999 Ulm, 1-12-1999 Ulm, 1999.12.1 Ulm, 1.12.1999 Ulm, 1.12.1999 Ulm, 1.12.1999 Ulm, 1.12.1999</p>
<p>DK EU Overensstemmelse certifikat</p> <p>Undertegnede GARDENA Kress + Kastner GmbH · Hans-Lorenser-Str. 40 · D-89079 Ulm bekræfter hermed, at enhederne listet herunder, ved afsendelse fra fabrikken, er i overensstemmelse med harmoniserede EU retningslinjer, EU sikkerheds standarder og produkt specifikations standarder. Dette certifikat træder ud af kraft hvis enhederne er ændret uden vor godkendelse.</p>	<p>Thomas Heinl Technische Leitung Technical Dept. Manager Direction technique Hoofd technische dienst Technical Director Direzione Tecnica Dirección Técnica Director Técnico Teknisk direktør</p> 

Deutschland
GARDENA Kress + Kastner GmbH
GARDENA Service
Hans-Lorenser-Straße 40
D-89079 Ulm
Produktfragen: (0731) 490-123
Reparaturen: (0731) 490-290

Argentina
Argensem S.A.
Venezuela 1075
(1618) El Talar - Buenos Aires

Australia
NYLEX Corporation Ltd.
25-29 Nepean Highway
P.O. Box 68
Mentone, Victoria 3194

Austria
GARDENA Österreich Ges. m.b.H.
Stettnerweg 11-15
2100 Korneuburg

Belgium
MARKT (Belgium) NV/SA
Sterrebeekstraat 163
1930 Zaventem

Brazil
M. Cassab
Av. das Nações Unidas, 20.882
Santo Amaro, CEP 04795-000
São Paulo - S.P.

Bulgaria / България
ДЕНЕКС ООД
Бул. "Г.М.Димитров" 16 ет.4
София 1797

Canada
GARDENA Canada Ltd.
100, Summerlea Road
Brampton, Ontario
Canada L6T 4X3

Chile
Antonio Martinic Y CIA. LTDA.
Gilberto Fuenzalida 185 Loc.
Las Condes - Santiago de Chile

Costa Rica
Compania Exim
Euroiberoamericana S.A.
350 Sur del Automercado
Los Yoses
San Pedro

Cyprus
FARMOKIPIKI LTD
P.O. Box 7098
74, Digeni Akrita Ave.
1641 Nicosia

Czech Republic
GARDENA spol. s.r.o.
Řípská 20a, č.p. 1153
62700 Brno

Denmark
GARDENA Danmark A/S
Naverland 8
2600 Glostrup

Finland
Habitec Oy
Martinkyläntie 52
01720 Vantaa

France
GARDENA France
Service Après-Vente
BP 50080
95948 ROISSY CDG Cedex

Great Britain
GARDENA UK Ltd.
27-28 Brenkley Way
Bleazard Business Park
Seaton Burn
Newcastle upon Tyne NE13 6DS

Greece
Agrokip G. Psomadopoulos & Co.
20, Lykourgou str.
Kallithaea - Athens

Hungary
GARDENA Magyarország Kft.
Késmárk utca 22
1158 Budapest

Iceland
Heimilistaeki hf
Saetun 8
P.O. Box 5340
125 Reykjavik

Republic of Ireland
Michael McLoughlin & Sons
Hardware Limited
Long Mile Road
Dublin 12

Italy
GARDENA Italia S.p.A.
Via Donizetti 22
20020 Lainate (Mi)

Japan
KAKUDAI Mfg. Co. Ltd.
1-4-4, Itachibori Nishi-ku
Osaka 550

Luxembourg
Magasins Jules Neuberg
Grand Rue 30
Case Postale No. 12
Luxembourg 2010

Netherlands
GARDENA Nederland B.V.
Postbus 50176
1305 AD ALMERE

Neth. Antilles
Jonka Enterprises N.V.
Sta. Rosa Weg 196
P.O. Box 8200
Curaçao

New Zealand
NYLEX New Zealand Limited
Private Bag 94001
South Auckland Mail Centre
10 Offenhauser Drive
East Tamaki, Manukau

Norway
GARDENA Norge A/S
Postboks 214
2013 Skjetten

Poland
GARDENA Polska Sp. z o.o.
Szymanów 9d
05-532 Baniocha

Portugal
MARKT (Portugal), Lda.
Recta da Granja do Marquês
Edif. GARDENA
Algueirão
2725-596 Mem Martins

Russia / Россия
АО АМИДА ТТЦ
ул. Мосфильмовская 66
117330 Москва

Singapore
Variware
Holland Road Shopping Centre
227-A 1st Fl., Unit 29
Holland Avenue
Singapore 1027

Slowenia / Croatia
Silk d.o.o. Trgovina
Brodišće 15
1236 Trzin

South Africa
GARDENA South Africa (Pty) Ltd.
P.O. Box 11534
Vorna Valley 1686

Spain
ANMI Andreu y Miriam S.A.
Calle Pere IV, 111
08018 Barcelona

Sweden
GARDENA Svenska AB
Box 9003
20039 Malmö

Switzerland
GARDENA Kress + Kastner AG
Bitzberg 1
8184 Bachenbülach

Ukraine / Украина
АОЗТ АЛЬЦЕСТ
ул. Гайдара 50
г. Киев 01033

Turkey
Dost Diş Ticaret Mümessilik A.Ş.
Yeşilbağlar Mah. Başkent
Cad. No. 26
Pendik - İstanbul

USA
GARDENA
3085 Shawnee Drive
Winchester, VA 22604

1739-08.960.01/0031
© GARDENA Manufacturing GmbH
D-89070 Ulm
<http://www.gardena.com>