

6500 SP Art. 1792
8000 SP Art. 1794
13000 SP Art. 1796

D Betriebsanleitung
Schmutzwasserpumpe

GB Operating Instructions
Dirty Water Pump

F Mode d'emploi
Pompe d'évacuation pour eaux chargées

NL Instructies voor gebruik
Vuilwaterpomp

S Bruksanvisning
Spillvattenpump

I Istruzioni per l'uso
Pompa sommersa per acqua sporca

E Manual de instrucciones
Bomba para aguas sucias

P Instruções de utilização
Bomba para águas sujas

DK Brugsanvisning
Dykpumpe til urent vand

GARDENA Dirty Water Pump

6500 SP / 8000 SP / 13000 SP

Welcome to the garden of GARDENA ...



Translation of the original instructions from German.
Please read these operating instructions carefully and observe the notes given. Use the instructions to familiarise yourself with the dirty water pump, its correct use, and the notes on safety.



For safety reasons, children under 16 as well as persons not familiar with these operating instructions should not use this dirty water pump.

→ Keep these operating instructions in a safe place.

Contents

1. Applications Range of Your GARDENA Dirty Water Pump	11
2. For Your Safety	12
3. Initial Operation	13
4. Operation	14
5. Cleaning	15
6. Trouble-Shooting	15
7. Storage	16
8. Technical Data	16
9. Service	17

1. Applications Range of Your GARDENA Dirty Water Pump

Intended use

GARDENA Dirty Water Pumps have been designed for private use around your house and garden. They are predominantly destined for drainage after flooding, transfer of liquids, draining containers, taking water from wells and shafts, draining boats and yachts as well as for water aeration and circulation for a limited period of time.

Liquids to be pumped

Liquids which can be handled by the GARDENA Dirty Water Pumps are the following: clean and slightly contaminated water, swimming pool water (prerequisite is the recommended dosage of additives) and soapy water.

GARDENA Dirty Water Pumps are able to convey dirty water containing particles with a diameter of up to 25 mm (for model 6500 SP) or 30 mm (for model 8000 SP / 13000 SP).

The pumps are fully submersible (waterproof sealed) and can be submerged down to a depth of 9 m into the liquid.

Please note



The GARDENA Dirty Water Pumps are not designed for continuous operation (e.g. continuous circulating operation) in a pond. Your pump's life will be shortened correspondingly by such operation.

Corrosive, easily combustible or explosive substances (e.g. gasoline, petroleum, nitro thinner), fats, oils, salt-water and waste water of toilets and urinals must not be pumped. The temperature of the liquid handled should not exceed 35 °C.

2. For Your Safety

Residual-current device

According to DIN VDE (German Electrical Engineers' Association) 0100, dirty water pumps may only be used in swimming pools, garden ponds, and fountains if the pump is operated via a residual-current device with a residual-current rating of ≤ 30 mA. The pump must not be operated when there are persons in the swimming pool or garden pond.

For safety reasons we recommend that you always operate the pump via a residual-current device (DIN VDE 0100-702 and 0100-738).

→ Please contact your electrician.

In Austria

In Austria, according to ÖVE B/EN 60 555 part 1 to 3, pumps which are used in swimming pools and garden ponds, and equipped with firm power cable should be fed via an ÖVE approved isolating transformer – rated voltage must not exceed 230 V.

In Switzerland

In Switzerland mobile appliances which are used outdoors, must be connected via a residual-current device.

Mains power

According to DIN VDE (German Electrical Engineers' Association) 0620, mains power cables must not have a smaller cross-section than the rubber-sheathed cables of the designation H05 RNF (model 6500 SP and 8000 SP) or H07 RNF (model 13000 SP). The cable length must be at least 10 m.

Data indicated on the type plate must match technical data of the mains supply.

→ Take care that the electrical connections are made within dry area, protected from flooding.

Protect plug and power cable from heat, oil and sharp edges.

→ Don't use the power cable for plugging off.

The power cable or the float switch must not be used for mounting or relocating the pump. For submerging or lifting/securing the pump, fix a rope to the pump's carrying handle.

Visual check

→ Before operating the pump, first make a visual check, if there is any damage of the pump (esp. regarding power cable and plug).

→ Observe the minimum water level and the max. delivery height (see 8. Technical Data).

A damaged pump must not be used.

→ In case of damage, please have the pump checked by our GARDENA Service Centre.

Manual operation

During manual operation, the pump must be switched off as soon as all the liquid has been pumped away.

→ Observe the pump at all times during manual operation.

Notes on use

→ Clear the outlet line before use.

Dry-running operation causes increased wear and is to be avoided. Therefore, in manual operation the pump must be immediately unplugged when water fails to flow.


Avoid running of the pump for more than 10 min. against closed delivery side of the pump.

Take care that the pump is located where the inlet openings at the suction base are obstructed neither completely nor partly.

Stand the pump on a brick if using in a pond.

Thermal motor protector

The pump is automatically switched off on overheating by the built-in thermal motor protector. After having cooled down, the motor automatically switches on again (see 6. Trouble Shooting).

Automatic deaerating valve

The automatic deaerating valve eliminates any air pockets in the pump. During this process, air escapes through the vent bores ④ and air bubbles appear underwater. This is not a defect of your pump, but serves to deaerate the pump.

It may take several seconds for the air to escape when the pump is immersed for the first time.

3. Initial Operation

Hose diameter	13 mm (1/2") 15 mm (5/8") 19 mm (3/4")	25 mm (1")	38 mm (1 1/2")
Hose connection of universal fitting ⑦			
Hose connection	Cut off topmost nipple at ⑧. The following connection kits are required for 13 mm to 19 mm connections: 13 mm (1/2"): GARDENA Pump Connection Set, Art. No. 1750 15 mm (5/8"): GARDENA Tap Connector, Art. No. (2)902, and Standard Hose Connector, Art. No. (2)916 19 mm (3/4"): GARDENA Pump Connection Set, Art. No. 1752 Best results in delivery capacity are achieved when using 38 mm (1 1/2") hoses.	Do not cut off any nipples.	Cut off top two nipples at ⑨.

The following connection kits are required for 13 mm to 19 mm connections:


13 mm (1/2"): **GARDENA Pump Connection Set, Art. No. 1750**

15 mm (5/8"): **GARDENA Tap Connector, Art. No. (2)902, and Standard Hose Connector, Art. No. (2)916**

19 mm (3/4"): **GARDENA Pump Connection Set, Art. No. 1752**

Best results in delivery capacity are achieved when using 38 mm (1 1/2") hoses.

Connecting the hose:



The universal fitting (7) allows you to connect all the hoses listed in the previous table.

1. Cut off nipples of the universal fitting (7), which are not needed, to match the hose connection.
2. Screw the universal fitting (7) onto the pump.
3. Connect the hose to the universal fitting (7).


We recommend that you secure 38 mm (1 1/2") and 25 mm (1") hoses additionally with a **GARDENA Hose Clip Art. No. 1591**.

Only for 13 mm (1/2") hose:

The universal fitting (7) can also be equipped with a **GARDENA Regulator Valve Art. No. 977** so that the contents of the outlet line do not flow back through the pump after pumping. The Regulator Valve can be ordered from your GARDENA dealer.

4. Operation

Automatic operation:



To ensure that the pump draws the water out, the water to be drained must be at least 10 cm deep.

The float switch (5) turns the pump on automatically when the water level exceeds the cut-in height and the water is pumped out.

The float switch (5) turns the pump off again as soon as the water level falls below the cut-out height.

1. Stand the pump on a firm surface
— or —
use a rope attached through the bore hole in the carrying handle (2) to immerse the pump in a well or shaft.
During automatic operation, ensure that the float switch (5) can move freely.
2. Plug the power cable (1) into a mains socket.


Adjusting the Cut-in and Cut-out Height:

The maximum cut-in height and minimum cut-out height (see 8. Technical Data) can be adjusted.

- Push the cable of the float switch (5) into the float switch lock (3).
Do not select a cable length that is too long or short to ensure that the float switch can turn on and off properly.
- The higher the opening of the float switch lock (3), the higher the cut-in and cut-out height.
 - The shorter the length of cable between the float switch (5) and the float switch lock (3), the lower the cut-in height and the higher the cut-out height.

The cable length between the float switch (5) and the float switch lock (3) must always be at least 10 cm.

Manual operation:



The pump remains in constant operation because the float switch is bypassed.


1. Push the float switch ⑤ onto the float switch lock ③ with the cable downward.
2. Stand the pump on a firm surface
— or —
use a rope attached through the bore hole in the carrying handle ② to immerse the pump in a well or shaft.
3. Plug the power cable ① into a mains socket.

The residual water height is only reached during manual operation since the float switch turns off the pump during automatic operation before this water level is reached.

5. Cleaning

Flushing the pump:

Cleaning the suction base and feed impeller:



The pumps are virtually maintenance-free.

After having pumped chlorinated swimming pool water or other liquids leaving residues, the pump should be rinsed with clear water.



Warning! Electric shock!

Risk of injury due to electric shock.

→ Disconnect the pump from the mains before cleaning the suction base and feed impeller.

1. Unscrew the 6 Phillips screws ⑧ (model 6500 SP: 4 Phillips screws) and pull the suction base ⑥ off the pump.
2. Clean the suction base ⑥ and the feed impeller ⑨.
3. Reinstall the suction base ⑥ and screw in the Phillips screws ⑧.

For safety reasons a damaged feed impeller ⑨ can only be exchanged by the GARDENA Service Centre.

6. Trouble-Shooting

Problem	Probable cause	Remedy
Pump is running, but doesn't deliver.	Air cannot escape, since pressure line is closed.	→ Open pressure line (e.g. kinked pressure pipe).
	Air locks in the suction base.	→ Wait for max. 3 minutes until the pump deaerates automatically over the vent valve. If necessary, switch off and start it again.
	Feed impeller clogged.	→ Disconnect plug and clean feed impeller (see 5. Cleaning).
	When starting the pump, water height falls below the min. water level.	→ Submerge pump deeper.

Problem	Probable cause	Remedy
Pump doesn't start or suddenly stops during operation.	Thermal overload switch has switched the pump off due to overheating.	→ Disconnect plug and clean feed impeller (see 5. Cleaning). Observe max. media temperature of 35 °C.
	No power.	→ Check fuses and electric connections.
	Dirt particles are jammed in the suction base.	→ Disconnect plug and clean suction base (see 5. Cleaning).
Pump runs, but output suddenly decreases.	Suction base is clogged.	→ Disconnect plug and clean suction base (see 5. Cleaning).



Attention!

Repairs on electrical parts should only be done by our GARDENA Service Centres.

If you have any problems with your Pump, please contact our Service.

7. Storage

Frost-free storage

Store the pump away from frost before the first frost sets in.

Disposal:

(in accordance with RL 2002/96/EC)



The product must not be added to normal household waste. It must be disposed of in line with local environmental regulations.

8. Technical Data

Type	6500 SP (Art. 1792)	8000 SP (Art. 1794)	13000 SP (Art. 1796)
Rated power	250 W	380 W	680 W
Max. delivery capacity	6,500 l/h	8,000 l/h	13,000 l/h
Max. pressure	0.5 bar	0.5 bar	0.9 bar
Max. delivery height	5 m	5 m	9 m
Max. submersion depth	9 m	9 m	9 m
Residual water height	30 mm	35 mm	35 mm
Contaminated water with particle size of max.	Ø 25 mm	Ø 30 mm	Ø 30 mm
Power cable	10 m H05 RNF	10 m H05 RNF	10 m H07 RNF
Pump connection	38 mm (1 1/2") / 25 mm (1") graduated nipple, option GARDENA Water hose Plug-in-system		
Min. water level for operation	80 mm	100 mm	100 mm
Weight approx.	4.3 kg	5.4 kg	7.0 kg
Max. media temperature	35 °C	35 °C	35 °C

Type	6500 SP (Art. 1792)	8000 SP (Art. 1794)	13000 SP (Art. 1796)
Mains voltage / mains frequency	230 V / 50 Hz	230 V / 50 Hz	230 V / 50 Hz
Min. cut-in height approx.	200 mm	205 mm	235 mm
Min./max. cut-out height approx.	65 mm / 165 mm	65 mm / 195 mm	65 mm / 225 mm
Noise level L_{WA}¹⁾	46 dB(A)	47 dB(A)	50 dB(A)


1) Measuring method according to EN 60335-1

Cut-in / Cut-out height

The cut-in and cut-out height varies.

The residual water height is only reached during manual operation (see 4. Operation).

Performance characteristics



9. Service

Warranty

GARDENA guarantees this product for 2 years (from date of purchase). This guarantee covers all serious defects of the unit that can be proved to be material or manufacturing faults. Under warranty we will either replace the unit or repair it free of charge if the following conditions apply:

- The unit must have been handled properly and in keeping with the requirements of the operating instructions.
- Neither the purchaser or a non-authorised third party have attempted to repair the unit.

The feed impeller is a wearing part and is not covered by the guarantee.

This manufacturer's guarantee does not affect the user's existing warranty claims against the dealer/seller.

If you have any problems with your pump, please contact our Customer Service or return the defective unit together with a short description of the problem directly to one of the GARDENA Service Centres listed on the back of this leaflet.

Product Liability

We expressly point out that, in accordance with the product liability law, we are not liable for any damage caused by our units if it is due to improper repair or if parts exchanged are not original GARDENA parts or parts approved by us, and, if the repairs were not carried out by a GARDENA Service Centre or an authorised specialist. The same applies to spare parts and accessories.

GB

EU Certificate of Conformity

The undersigned

GARDENA Manufacturing GmbH Hans-Loreenser-Str. 40 · D-89079 Ulm

hereby certifies that, when leaving our factory, the units indicated below are in accordance with the harmonised EU guidelines, EU standards of safety and product specific standards.

This certificate becomes void if the units are modified without our approval.

Description of the units:	Dirty-Water Pump
Types:	6500 SP / 8000 SP / 13000 SP
Art. No.:	1792 / 1794 / 1796
EU directives:	Machinery Directive 98/37/EC : 1998 2006/42/EC : 2006 Electromagnetic Compatibility 2004/108/EC Low Voltage Directive 2006/95/EC Directive 93/68/EC
Harmonised European standards:	EN 292-1 EN 292-2 EN 60335-1 EN 60335-2-41
Year of CE marking:	2001

Ulm, 29.05.2001



Thomas Heinl
Technical Dept. Manager

Deutschland / Germany GARDENA Manufacturing GmbH Service Center Hans-Lorenser-Straße 40 D-89079 Ulm Produktfragen: (+49) 731 490-123 Reparaturen: (+49) 731 490-290 service@gardena.com	Croatia KLIS d.o.o. Stanciceva 79 10419 Vukovina Phone: (+385) 1 622 7770 gardena@klis-trgovina.hr	Italy GARDENA Italia S.p.A. Via Donizetti 22 20020 Lainate (Mi) Phone: (+39) 02.93.94.79.1 info@gardenaitalia.it	Singapore Hy - Ray PRIVATE LIMITED 40 Jalan Pemimpin #02-08 Tat Ann Building Singapore 577185 Phone: (+65) 6253 2277 hyray@singnet.com.sg
Argentina Argensem® S.A. Calle Colonia Japonesa s/n (1625) Loma Verde Escobar, Buenos Aires Phone: (+54) 34 88 49 40 40 info@argensem.com.ar	Cyprus FARMOKIPIKI LTD P.O. Box 7098 74, Digeni Akrita Ave. 1641 Nicosia Phone: (+357) 22 75 47 62 condam@spidernet.com.cy	Japan KAKUICHI Co. Ltd. Sumitomo Realty & Development Kojimachi BLDG., 8F 5-1 Nibanncyo, Chiyoda-ku Tokyo 100-0084 Phone: (+81) 33 264 4721 m_ishihara@kaku-ichi.co.jp	Slovak Republic GARDENA Slovensko, s.r.o. Panónska cesta 17 851 04 Bratislava Phone: (+421) 263 453 722 info@gardena.sk
Australia Nylex Consumer Products 50-70 Stanley Drive Somerton, Victoria, 3062 Phone: (+61) 1800 658 276 spare.parts@nylex.com.au	Czech Republic GARDENA spol. s r.o. Řípská 20a, č.p. 1153 627 00 Brno Phone: (+420) 800 100 425 gardena@gardenabrn.cz	Luxembourg Magasins Jules Neuberg 39, rue Jacques Stas Luxembourg-Gasperich 2549 Case Postale No. 12 Luxembourg 2010 Phone: (+352) 40 14 01 api@neuberg.lu	Slovenia GARDENA d.o.o. Brodisce 15 1236 Trzin Phone: (+386) 1 580 93 32 servis@gardena.si
Austria / Österreich GARDENA Österreich Ges.m.b.H. Stettnerweg 11-15 2100 Korneuburg Tel.: (+43) 22 62 7 45 45 36 kundendienst@gardena.at	Denmark GARDENA Norden AB Salgsafdeling Danmark Box 9003 S-200 39 Malmö info@gardena.dk	Netherlands GARDENA Nederland B.V. Postbus 50176 1305 AD ALMERE Phone: (+31) 36 521 00 00 info@gardena.nl	South Africa GARDENA South Africa (Pty) Ltd. P.O. Box 11534 Vorna Valley 1686 Phone: (+27) 11 315 02 23 sales@gardena.co.za
Belgium GARDENA Belgium NV/SA Sterrebeekstraat 163 1930 Zaventem Phone: (+32) 2 7 20 92 12 Mail: info@gardena.be	Finland Habitec Oy Martinkyläntie 52 01720 Vantaa	Neth. Antilles GARDENA PARIS NORD 2 69, rue de la Belle Etoile BP 57080 ROISSY EN FRANCE 95948 ROISSY CDG CEDEX Tél. (+33) 0826 101 455 service.consommateurs@gardena.fr	Spain GARDENA IBÉRICA S.L.U. C / Basauri, nº 6 La Florida 28023 Madrid Phone: (+34) 91 708 05 00 atencioncliente@gardena.es
Brazil Palash Comércio e Importação Ltda. Rua Américo Brasiliense, 2414 - Chácara Sto Antônio São Paulo - SP - Brasil - CEP 04715-005 Phone: (+55) 11 5181-0909 eduardo@palash.com.br	Great Britain GARDENA UK Ltd. 27-28 Brenkley Way Bleazerd Business Park Seaton Burn Newcastle upon Tyne NE13 6DS info@gardena.co.uk	New Zealand NYLEX New Zealand Limited Building 2, 118 Savill Drive Mangere, Auckland Phone: (+64) 0800 22 00 88 spare.parts@nylex.com.au	Sweden GARDENA Norden AB Försäljningskontor Sverige Box 9003 200 39 Malmö info@gardena.se
Bulgaria DENEX LTD. 2 Luis Ahalier Str. - 7th floor Sofia 1404 Phone: (+359) 2 958 18 21 office@denex-bg.com	Greece Agrokip Psomadopoulos S.A. Ifaioustou 33A Industrial Area Koropi 194 00 Athens Greece V.A.T. EL093474846 Phone: (+30) 210 66 20 225 service@agrokip.gr	Norway GARDENA Norden AB Salgskontor Norge Karlihaugveien 89 1086 Oslo info@gardena.no	Switzerland / Schweiz GARDENA (Schweiz) AG Bitzberg 1 8184 Bachenbülach Phone: (+41) 848 800 464 info@gardena.ch
Canada GARDENA Canada Ltd. 100 Summerlea Road Brampton, Ontario L6T 4X3 Phone: (+1) 905 792 93 30 info@gardenacanada.com	Portugal GARDENA Portugal Lda. Recta da Granja do Marquês Edif. GARDENA Algueirão 2725-596 Mem Martins Phone: (+351) 21 922 85 30 info@gardena.pt	Turkey GARDENA / Dost Dış Ticaret Mümessilik A.Ş. Sanayi Çad. Adil Sokak No. 1 Kartal - İstanbul Phone: (+90) 216 38 93 939 info@gardena-dost.com.tr	Ukraine / Украина ALTTEST JSC 4 Petropavlivska Street Petropavlivska Borschahivka Town Kyivo Svyatoslyny Region 08130, Ukraine Phone: (+380) 44 459 57 03 upy@alttest.kiev.ua
Chile Antonio Martinic y Cia Ltda. Cassillas 272 Centro de Cassillas Santiago de Chile Phone: (+56) 2 20 10 708 garfar_cl@yahoo.com	Hungary GARDENA Magyarország Kft. Késmárki utca 22 1158 Budapest Phone: (+36) 80 20 40 33 gardena@gardena.hu	Romania MADEX INTERNATIONAL SRL Soseaua Odaii 117-123, Sector 1, Bucureşti, RO 013603 Phone: (+40) 21 352 76 03 madex@ines.ro	USA Melnor Inc. 3085 Shawnee Drive Winchester, VA 22604 Phone: (+1) 540 722-9080 service_us@melnor.com
Costa Rica Compania Exim Euroiberoamericana S.A. Los Colegios, Moravia, 200 metros al Sur del Colegio Saint Francis - San José Phone: (+506) 297 68 83 exim_euro@racsa.co.cr	Iceland Ó. Johnson & Kaaber Tunguhalsi 1 110 Reykjavík oqj@ojk.is	Russia / Россия ООО ГАРДЕНА РУС 123007, г. Москва Хорошевское шоссе, д. 32A Тел.: (+7) 495 647 25 10 info@gardena-rus.ru	1792-20.960.09/0507 © GARDENA Manufacturing GmbH D-89070 Ulm http://www.gardena.com